

WE LOVE SOCIAL MEDIA


FOLLOW US



www.vonmaehlen.com



REMOVE | Pull the tab on the base of the Backflip® slightly upwards and push.



ATTACH | Position Backflip® so that the logo is right side up. Attach Backflip® by sliding it sideways onto the base, then snap it back into place with light pressure.

BACKFLIP® MAG
USER MANUAL

VONMÄHLEN
Northern Germany



Backflip® Mag, the magnetic phone grip, snaps easily to your phone for a secure hold (no sticky residue) with an integrated kickstand feature.

1.

Simply position Backflip® Mag on the back of your phone for the most comfortable fit. Snap it on and go!



2.

Backflip® Mag is now ready for use.



3.

Flip the disc through the ring for the kickstand feature.

