

# QUICK-START GUIDE

FindMe Tag


## What's in the Box



1x




1x




1x

## Before First Use



## Power on



## Pairing

### Pair with iPhone

(Apple Find My)

1. Open the **Find My** app
2. Tap **Items**
3. Select **Add Item**
4. Choose **Other Supported Item**
5. Select **Vonmählen FindMe Tag**

Follow the on-screen instructions.

### Pair with Android™

(Google Find Hub)

1. Turn on the device
2. Tap **Connect** when prompted
3. Open the **Find Hub** app  
(If not already installed, download it from the Google Play Store.)
4. Confirm pairing

Follow the on-screen instructions.

## Important

If not paired within 10 minutes, the device automatically powers off to preserve battery.

## Device Controls

### 1. Check Status

- Double-press the button
- Short tone = connected
- Long tone = powered on, not connected
- No sound = powered off

### 2. Power Off

Press 5 times within 2 seconds.

### 3. Factory Reset

Press 4 times quickly. When you hear a tone, press and hold for 5 seconds until the reset tone plays.

### 4. Device Identification Mode

Press 6 times within 2 seconds. (For service purposes only.)

## How location works

Location is powered by the Apple Find My or Google Find Hub network. When your item is out of Bluetooth range, nearby compatible devices securely and anonymously relay its location. Only you can see your item's location. Location data is encrypted.

## Lost Mode


Enable Lost Mode in the app to display a message and contact information for anyone who finds your item.

## Tech Specs

Battery Type	Replaceable CR2032 Lithium Battery
Battery Capacity	220mAh
Battery Life	8 – 10 Months
Bluetooth®	Bluetooth®Version: 5.2
Notification Sound	70 – 90 dB
Dust- and Splash-Water Resistant	IP64
Worldwide Tracking	Works with Apple FindMy Works with Android Find Hub
Materials	ABS, PA / Nylon, recycled ABS, recycled PC, Zinc Alloy
Product Size	L 32.2 × W 32.2 × H 8 mm
Weight	8.5g

We reserve the right to make changes without notice in the interest of technical progress.

## Battery Replacement



1. Open from the notch side.
2. Insert a new CR2032 battery (positive side up)
3. Close the device
4. Press and hold for 5 seconds to restart

## Legal Requirements

To use the Find My app to locate this item, it is recommended to have the latest version of iOS, iPadOS, or macOS. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Google, Android, and Find Hub are trademarks of Google LLC.

Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users.