



# QUICK-START GUIDE

FindMe


## What's in the Box



## Functions



## Wireless Charging



### 1. Positioning for Charging

On the back of the device, a marking indicates the wireless charging area. Align this marking with the center of the wireless charger for optimal charging.

### 2. Charging Light Indicators

- Red Light:** Stays on while charging.
- Green Light:** Turns on when the device is fully charged.
- Blue Light:** Flashes when the device powers on or off.

### 3. How long does the battery last when fully charged?

The built-in 100mAh lithium battery is rechargeable and lasts approximately 6 months on a full charge.

### 4. Wireless Charging Time

Charging takes approximately 45 minutes.

## Tech Specs

Battery Type	Integrated Rechargeable Li-ion Polymer Cell
Battery Capacity	100mAh
Wireless Charging (Input)	Wirelessly Rechargeable
Bluetooth®	Bluetooth® Version: 5.2
Standby	up to 6 Months
Notification Sound	70 - 90 dB
Water and Dust Resistant	IP67
Material (Card only)	PVC
Product Size	L 85.5 × W 54 × H 1.6 mm
Weight	11.5g

We reserve the right to make changes without notice in the interest of technical progress.

## Quick Instruction

### 1. Turn on the device

- Press and hold the Button for **5 seconds**. The device will be beep and turn on.

### 2. Pair the device

- Open the **Find My** app.
- Hold the device close to your iPhone, tap the **Items** tab, then tap + and select **Add Other Item**.
- Tap **Connect**.
- Type a name for your device and select an emoji.
- Tap **Agree** to acknowledge that this item will be linked to your Apple ID.
- Tap **Finish**.

### 3. Enable Lost Mode

- Open the **Find My** app, tap the **Items** tab, then select your item.
- Under **Lost Mode**, tap **Enable**.
- Read the instructions, tap **Continue**, and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap **Activate** to complete the setup.

### 4. Remove the device

- Open the **Find My** app, tap the **Items** tab,

then select your item.

- Tap **Remove Item**, then tap **Remove** again to complete the process.

### Note

After removing the device in the app, the device will beep, and the light will flash quickly six times, it will not shut down and will be in the pairing mode. If no re-pairing occurs within 10 minutes, the device will leave the pairing state, and it will not be possible to pair it with the app. If you need to re-pair the device, press the device button once. The device will beep, and the light will flash once, indicating that it has entered pairing mode and can be re-paired with the app.

## MAIN FUNCTIONS

### 1. Locate your item

- If your missing item isn't nearby, the **Find My** app can still help you track it down using the **Find My** network.

### 2. Play Sound

- Open the **Find My** app, tap the **Items** tab, then select your item.
- Tap **Play Sound**. The device will beep, making it easier to locate.

## Instruction

### 1. Power On

Press and hold the button for 5 seconds. The device will beep, the light will flash 3 times, and the device will turn on.

### 2. Device Status Confirmation

Double-click the device button, the device will beep, and the light will flash 3 times, indicating that the device is working when paired. If the device does not ring, the device is off. Long press the button for 5 seconds to turn it on. When the device is not paired it will beep only, without light flash indication.

### 3. Re-entering Pairing Mode

After removing the device in the app, it will beep and the light will flash 6 times. It will not shut down and will remain in pairing mode. If no re-pairing occurs within 10 minutes, the device will leave pairing mode. To re-enter pairing mode, press the device button once. The device will beep, and the light will flash once, indicating it is ready to be paired again.

### 4. Factory Reset

First, remove the item from the **Find My** app. Then, after the device is powered on, double-click the device button, the device will beep. When you hear the device prompt sound, press and hold the device button immediately, and after 2 seconds, the device will beep 6 times, and the LED flashes 6 times. Don't let go of the button, continue to press and hold the button until the device beeps again, the light flashes 3 times, release the button, and at this point, the factory reset is complete. The device is now ready to be paired.

### 5. Power Off

When the device is on, press the button 5 times within 2 seconds. The device will beep, the light will flash 3 times, and it will power off.

## FAQ

### 1. When can the device be located?

When an item is separated from its owner for a period of time, it can be detected by other Apple devices that are part of the **Find My** network. The owner will then receive location updates for the device.

### 2. How can I confirm whether the device is turned on?

Double-click the device button. If the device beeps, it is on. If it does not beep, it is off. Press and hold the button for 5 seconds to turn it on. When paired, the device will beep and additionally flashes 3 times.

### 3. How is my privacy protected?

Only you can see the location of your item. Your location data and history are never stored on the item itself. Devices that relay the location of your item remain anonymous, and all location data is encrypted. Not even Apple or Vonmählen can access the location of your device or the identity of the device that helps find it.

### 4. How do I replace the battery?

The battery cannot be changed. It is rechargeable.

### 5. What is the Find My network, and how does it work?

The Apple **Find My** network allows you to locate compatible personal items using the **Find My** app on your iPhone, iPad, iPod touch, Mac, or Apple Watch. Simply pair your product with the **Find My** app to view it alongside your Apple devices. If your item goes missing, you can enable **Lost Mode** to display a message and contact information to anyone who finds it. The **Find My** network is encrypted and anonymous, ensuring that no one, not even Apple or Vonmählen, can view your device's location.

## Legal Requirements

To use the Find My app to locate this item, it is recommended to have the latest version of iOS, iPadOS, or macOS. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

**WE LOVE SOCIAL MEDIA**  
Follow us

